Pulsar

EN**

D.F

Pulsar

CODE: TYPE: EN54-5A28 v.1.1/VII EN54 27,6V/5A/2x28Ah power supply unit for fire alarm systems

RED POWER



Power supply unit for fire systems used in building industry. Declared performance: Fire safety. Certificate of constancy of performance: 1438-CPR-0385 Certificate of admittance: 2174/2014 Conformity: EN 54-4:1997+AC:1994+A1:202+A2:2006 EN 12101-10:2005+AC:2007



"This product is suitable for the systems designed in compliance with the standards EN 54-4 and EN 12101-10"

Requirements	Requirements according to standards	PSU EN54-5A28
External Power Supply failure indication	YES	YES
Two independent power supply outputs protected against short-circuit	YES	YES
Temperature-compensated battery charging	YES	YES
Measurement of the resistance of the battery circuit	YES	YES
Low battery indication	YES	YES
Deep discharge battery protection	YES	YES
Protection against short-circuit of the battery terminals	YES	YES
Blown battery fuse indication	YES	YES
Charging circuit failure indication	YES	YES
Low output voltage indication	YES	YES
High output voltage indication	YES	YES
Indication of power supply failure	YES	YES
Overvoltage protection	YES	YES
Short-circuit protection	YES	YES
Overload protection	YES	YES
Output of collective failure ALARM	YES	YES
EPS technical output	YES	YES
APS technical output	YES	YES
PSU technical output	-	YES
Input of an external failure indication EXTi	-	YES
Controlled relay output EXTo	-	YES
Remote battery test	-	YES
~230 V mains supply voltage measurement	-	YES
LED optical indication	-	YES
Tamper indicating enclosure opening	-	YES

EN54/LED series power supply unit Power supply for fire alarm systems 27,6 V DC



PSU features:

- In accordance with standards: EN 54-4:1997+AC:1999+A1:2002+A2:2006, EN 12101-10:2005+AC:2007
- 27,6 V DC/ 5 A uninterruptible power supply
- battery housing for two 28 Ah/12 V batteries
- independently protected outputs AUX1 and AUX2
- high efficiency 84%
- low level of voltage ripple
- microprocessor-based automation system
- intelligent PSU overload protection
- · measurement of the resistance of the battery circuit
- automatic temperature-compensated charging
- battery test
- two-stage battery charging process
- accelerated battery charging
- · monitoring of the continuity of the battery circuit
- monitoring of the battery voltage
- monitoring of the battery fuse
- monitoring of charging and maintenance of the batteries
- deep discharge battery protection (UVP)
- battery overcharge protection
- battery output protection against short-circuit and reverse connection
- monitoring of the load current
- output voltage control
- fuse monitoring of AUX1and AUX2 outputs
- ~230 V mains supply voltage measurement
- "SERIAL" communication port with implemented MODBUS RTU protocol
- Power Security" is a free application for remote monitoring of power supplies (for PC and Android Phones)

- remote monitoring (options: Ethernet, RS485)
- remote battery test (additional modules required)
- cooperation with optional EN54-LB4 or EN54-LB8 fuse modules
- optical indication of PSU overload OVL
- acoustic indication of failure
- adjustable delay for ~230 V power loss indication
- relay output of collective failure ALARM
- input of collective failure EXTi
- controlled relay output EXTo
- technical inputs/outputs with galvanic isolation
- EPS technical output indicating ~230 V power loss
- PSU technical output indicating PSU failure
- · APS technical output indicating battery failure
- internal memory of PSU operating status
- optical indication LED panel
 - output current readings
 - output voltage readings: AUX1, AUX2
 - resistance of the battery circuit
 - ~230 V mains voltage readings
 - failure codes with history
- protections:
 - SCP short-circuit protection
 - OLP overload protection
 - OHP overheat protection
 - OVP overvoltage protection
 - Surge protection
 - Antisabotage protection Tamper
- closing the enclosure lock
- convection cooling
- warranty 5 years from the production date

General description

The buffer power supply has been designed for an uninterrupted supply of fire alarm systems, smoke and heat control systems, fire protection equipment and fire automatics requiring stabilized voltage of **24 V DC (± 15%)**. The PSU is fitted with two independently protected outputs AUX1 and AUX2, which supply voltage of **27,6 V DC** with a total output current:

Continuous operation Output current Imax a=3,5 A

Instantaneous operation Output current Imax b=5 A

In case of power loss, the PSU switches to battery power, providing uninterruptible power supply. The PSU is enclosed in a metal casing (RAL 3001 - red) with battery housing for two 28 Ah/12 V batteries. The PSU works with maintenance-free lead acid batteries made with AGM technology or gel technology.


EN54/LED series power supply unit Power supply for fire alarm systems 27,6 V DC



Output current 20,0 Com Com	S A Hz W
Current consumption0,95Power frequency50 HPSU's power138Efficiency84%Output voltage at 20 °C22,020,0Output currentComCom	łz W
Power frequency 50 H PSU's power 138 Efficiency 84% Output voltage at 20 °C 22,0 20,0 0utput current	W
PSU's power 138 Efficiency 84% Output voltage at 20 °C 22,0 20,0 0 Output current Com	
Output voltage at 20 °C 22,0 20,0 20,0 Output current Con	
20,0 Output current Con	
Output current Con) V÷ 27,6 V DC – buffer operation
	V+ 27,6 V DC – battery-assisted operation
	ntinuous operation: Imax a=3,5 A antaneous operation: Imax b=5 A
	m Ohm
	iV p-p max.
1-7	78mA
	tion ! If the power supply is connected with the communication interface or module, additional current consumption should be considered.
Battery charging current 1,5	
Coefficient of temperature compensation of the	
battery voltage	nV/ °C (-5 °C ÷ 40 °C)
	t < 23 V, during battery mode
Overvoltage protection OVP	0,5 V, disconnection of the output voltage (AUX+ disconnection), automatic
	B A – current limit, F _{AUX} melting fuse (failure requires fuse replacement)
	dware - Software
Battery circuit protection SCP and reverse	A ourront limit E molting from (failure requires from real-second)
polarity connection F10 Deep discharge battery protection UVP	A- current limit, F _{BAT} melting fuse (failure requires fuse replacement)
0<2	$10 \text{ V} (\pm 2\%) - \text{disconnection (+BAT) of the batteries,}$
	roswitch TAMPER
	$pe - electronic, max 50mA/30 V DC, galvanic isolation 1500 V_{RMS}$
- EPS FLT; indicating AC power failure - del pane	lay time approximately 10s/1m/10m/30m (+/-5%) – configured from the LED el
- APS FLT; indicating battery failure - typ - PSU FLT; indicating PSU failure	e – electronic, max 50mA/30 V DC, galvanic isolation 1500 V_{RMS}
	e – relay: 1 A@ 30 V DC/50 V AC
	JTION! In Fig.2 the set of contacts shows a potential-free status of the relay,
	ch corresponds to power supply failure.
	age "ON" – 10÷30 V DC
	age "OFF" – 0÷2 V DC
	el of galvanic isolation 1500 V _{RMS}
	@ 30 V DC /50 V AC
	Ds on the PCB of the power supply unit,
- LE	D panel
	output current readings
Optical indication:	output voltage readings: AUX1, AUX2
	resistance of the battery circuit
	mains supply voltage failure endes and history
Acoustic indication: - pie	failure codes and history accelectric indicator ~75 dB /0.3 m
Fuses:	
	3 A / 250 V
) A / 250 V
	3 A / 250 V
- F _{AUX2} F 6,	3 A / 250 V
	6485 "INTR" interface; RS485 communication
(not included) - Etr	nernet "INTE" interface; Ethernet communication
- R3	6485-Ethernet "INTRE" interface; RS485-Ethernet communication
	environmental class (EN12101-10:2007), -5 °C÷75 °C
Enclosure Stee Enclosure dimensions W=4	el plate DC01_1,2mm, color: RAL 3001 (red) 420_H=420_D+D1=182 + 8 [+/- 2mm]
	+20 H=420 D+D₁=182 + 8 [+/- 2mm] :425 H₁=425 [+/- 2mm]
	2/11,5 kg
2x28	B Ah/12 V (SLA) max. x 180 x 175mm (WxHxD) max H↑ W
Closing	lock
	ificate of constancy of performance CNBOP-PIB,
Certificates, declarations, warranty Cert	ifficate of approval CNBOP-PIB, RoHS, 5 years from the production date
The	enclosure does not adjoin the mounting surface so that cables can be led.
	vection cooling.

Pulsar

Parameters remote control system. (additional modules required)



O PowerSecurity					
Power Supplies Windows	Language Help				
e 🚛 Areal					
99.12 B 🚰 Area2	Preview Charts History		Preview Charts History		
- · · · · · · · · · · · · · · · · · · ·			G IN		
	RED P	FAUX1	RED POWER		
	AC EN		AC	EN54	AUX
	228V 27,6V		228V	27,6V / 5A	1 27.6V
	FBAT	FAUX2	FBAT	Fau	
		2 27,5V		_	2 27,6V
		Σ 2,6A			— ∑ 3,1A
	BAT		BAT		
					EDO
	21,1V NC	EXTO EPS	21,01	EXTO	EPS
	T 26°C or	PSU	⊤ 26°C	on	PSU
	R 0,12Ω	EXTI APS	R 0,12Ω	EXTi	APS
		TAMPER Alarm			Alarm
		AMPER - AldIII	TEST		Alam
	© PSU3 Preview Charts History				
	© PSU3		© PSU4		
	© PSU3 Preview Charts (History) Q 114	OWER	PSU4 Preview Charts History	RED POWER	
	PHU3 Prever [Ourts Helory] Th RED P	OWER FAIX1	PSU4 Preview Charts History	RED POWER	
	Oracle Preter Ouris (Netror) Tel C EN	OWER FAUX	O PSJ4 Preview Charts (Helory)	RED POWER EN54	
	PHU3 Prever [Ourts Helory] Th RED P	OWER FAUX1 54 1 27,6V	O PSLH Proview Charts Helony Th	RED POWER	AUX 1 0,0V
	O (2010) Prever Carts Hellowy O Tél RED P AC EN: 229V 27,6V	OWER 54 AUX 1 27 6V	© PS14 Profile Clasts History C 11+ AC 230V	RED POWER EN54	AUX 1 0,0V 2 27,5V
	O (2010) Prever Carts Hellowy O Tél RED P AC EN: 229V 27,6V	OWER FAUX1 54 1 27,6V	© PS14 Profile Clasts History C 11+ AC 230V	RED POWER EN54	AUX 1 0,0V
	Preme: Outris (Netror) AC 229V FGAT 27,6V	OWER 54 //2A FAIN2 2 27,6V	O ISSA Prese: Outri Intory 0 18 AC 230V FBAT	RED POWER EN54	AUX 1 0,0V 2 27,5V
	Oracle Premer: Ourse (Netror)	OWER 54 1 27,6V 2 27,6V 2 1,8A	O ISUA Proven Clarts (Moor) O 19 AC 230V FRAT BAT	RED POWER EN54 27,6V / 7A	AUX 1 0,0V 2 27,5V 2 3,2A
	0 mm Preme: Clauts Mitry 0 fb 229V FINT 0 Z7,6V C NR	OWER 54 1 27,6V 2 27,6V 2 1,8A EXTO EPS	O ISJA Prome: Clarit (Micry) O IA AC 230V FRAT BAT U 27,7V	RED POWER EN54 27,6V / 7A Fan	AUX 1 0,0V 2 27,5V 2 3,2A EPS
	Oracle Premer: Ourse (Netror)	OWER 54 1 27,6V 2 27,6V 2 1,8A EXTo EPS	O ISUA Proven Clarts (Moor) O 19 AC 230V FRAT BAT	RED POWER EN54 27,6V / 7A Fat	1 0,0V 2 27,5V 2 3,2A
	0 ISM Preme: [Outs] (Mbry] 0 If # 2299 Finat 0 Z7,6V 0 Z7,6V 0 Z7,6V 0 Z7,6V	OWER 54 1 27,6V 2 27,6V 2 1,8A EXTo EXTo EXTo EXTo EXTo	O ISJA Prome: Clarit (Micry) O IA AC 230V FRAT BAT U 27,7V	RED POWER EN54 27,6V / 7A Fan	AUX 1 0,0V 2 27,5V 2 3,2A EPS
	0 mm Preme: Clauts Netry 0 fe 229V F DAT 27,6V T 26°C R 0,11Ω	OWER AUX 54 1 27,6V 7/2A 2 27,6V 2 1,8A EXTo PSU EXTi APS	0 ISJA Prome: Oats (Marcy) 0 Id 230V FRAT U 27,7V T 26°C R 0,110	RED POWER EN54 27,6V / 7A EXTo on EXTo	AUX 1 0,0V 2 27,5V 2 3,2A EPS PSU APS
	0 mm premerio (Dartis) (Metry 0 ftel 229V F DAT 27,6V T 26°C R 0,11Ω	OWER 54 1 27,6V 2 27,6V 2 1,8A EXTo EXTo EXTo EXTo EXTo	O ISJA Prome: Clasts (Micry) AC 230V FRAT U 27,7V T 26°C	RED POWER EN54 27,6V / 7A Fat	1 0,0V 2 27,5V 2 3,2A EPS PSU

Pulsar


Remote monitoring (options: Ethernet, RS485).

The PSU has been adjusted to operate in a system that requires a remote control of the parameters in a monitoring centre. Transmitting data concerning PSU status is possible due to an additional, external communication module responsible for communication in Ethernet or RS485 standard. Different connection topologies, presented later in this chapter, are only a part of possible communication schemes. More examples can be found in the manuals dedicated to individual interfaces.

ETHERNET network communication.


Communication in the Ethernet network is possible due to the additional interfaces: Ethernet "INTE" and RS485-ETH "INTRE", according to the IEEE802.3 standard.

The Ethernet "INTE" interface features full galvanic isolation and protection against surges. It should be mounted inside the enclosure of the PSU.



Ethernet communication using the RS485-Ethernet "INTE" interface.

The RS485-ETHERNET "INTRE" interface is a device used to convert signals between the RS485 bus and the Ethernet network. For proper operation, the unit requires an external power supply in the range of 10÷30 V DC e.g. drawn from a PSU of the EN54 series. The physical connection of the interface takes place under galvanic isolation. The unit is mounted in a hermetic enclosure protecting against adverse environmental conditions.




Ethernet communication using the RS485-Ethernet "INTRE" interface.




Fuse modules EN54-LB4 and EN54-LB8

Fuse modules EN54-LB4 and EN54-LB8 allow to connect 4 or 8 receivers to the PSU. Output state is indicated by green LEDs.

Blown fuse signal is transmitted to the input of collective failure EXTi (ALARM) and saved in the internal memory of PSU. The PSU's relay output can also be used for remote control, including external optical indication.



The connection of fuse module: EN54-LB4.



The connection of fuse module: EN54-LB8.